

# EvaCore Waterproof Floors

## Installation Instructions

EvaCore may be floated or installed using a direct glue-down method (Depending on product).

### Before installation

Ensure that the subfloor is clean, sound, dry and level to 3/16" per 10' radius.

Shuffle planks so that optimum variation in patterns is achieved.

Inspect all flooring for manufacture defects.

Room temperature should always be close to 70 degrees with humidity between 30-50%

EvaCore is 100% waterproof, but anything you put on them probably is not. Make sure to test for moisture before you install.

### Tools needed:

Crosscut power saw

3M Scotch Blue Tape

Rubber Mallet

Knife

### Subfloor types

CDX Underlayment Grade Plywood

Underlayment grade particle board

¾" OSB

Concrete slab

Hardwood or laminate

Ceramic tile

LVT or Sheet Vinyl

### Installation

(For glue down method, use only XL Brand Stix 2230 Adhesive.)

Begin at an outside wall where you can usually find a straight line.

Start with a cut piece with cut end towards the left wall.

Face tongue-side toward the wall.

Use ¼" spacer at the wall.

Stagger end joint at least 8".

Always begin a row at a wall.

Snug end joints.

Start the next row keeping all joints tight.

Final row may be cut lengthwise.

For installation under a door jamb, the top lip of groove may be reduced by cutting with a knife.

(For Click Installation)

Tap in end joints.

Align next row piece with tongue-side fitting into groove of first row.

Tap in a downward/forward motion until snug.

Final row may be cut lengthwise.

For installation under a door jamb, the top lip of groove may be reduced by cutting with a knife.